



TM/MC/MR


E1213000BN

Single Handle Touchless Kitchen Faucet



How to order replacement parts:

To order replacement parts call our toll free customer service line at
1-866-789-2273 or your local costco representative.



1	Index Button-Cold/Hot	A66D558
2	Metal Handle Assembly	A662522
3	Trim Cap Assembly	A663977
4	Locking Nut	A104077
5	Ceramic Disc Cartridge	A507169N
6	Spout Tube Assembly	A542003
7	Hand Spray Assembly	A528024N-54
8	Screw (M5 * 5mm L)	A008003
9	Hose	A515111W
10	Weight	A504716
11	Shank Assembly	A504076
12	Cover Plate and Putty Plate	A667003-T
13	Filter Check Valves Adapter Assembly	A613263W
14	Control Box	A663911N
15	O-Ring set	A668178N
16	Battery Box	A543113
17	Hex Wrench (H4 * 20 mm L * 70 mm L)	A031011NI
18	Hex wrench (H2.5mm * 11mm L * 53mmL)	A031217NI
19	Screw	A668088ZA